




Dimensions - Stetsbar for Fender 3 Hole Hard-Tail Bridge

This document shows a top down view of the Hard-Tail baseplate and provides measurements for all of the critical dimensions that may be needed to ensure the unit will fit correctly to the guitar.

For more information please contact your regional Stetsbar support center.



REAR

- A. Scale length from front of baseplate - $19/32$ inch or 15 mm.
- B. Scale length A to mounting holes B - $3/4$ inch or 19 mm.
- C. Center point of the 3 holes - $1 \frac{9}{32}$ inch or 32.5 mm.
- D. Distance between mounting holes - $7/8$ inch or 23 mm.

Baseplate width $3 \frac{1}{4}$ inch or 82.5 mm.

Baseplate length $3 \frac{1}{2}$ inch or 89 mm.

Stetsbar bridge height measured at the top E saddle should be:

Minimum $11/16$ inch 17.5mm

Maximum $13/16$ inch or 20.5mm